GENERAL PARTS LIST

Please indicate the log splitter model when ordering parts.

1 - 2" ball coupler
2 - coupler latch assembly
3 - safety chains & hooks
4 - wire harness assembly
5 - front stop assembly
6 - stand assembly
7 - stand locking pin
8 - Transport Canada VIN certification
9 - knife and slider assembly
10 - log shelf (2)
11 - frame assembly
12 - slide pad kit
13 - rubberrride suspension (non-rubberride: 1" spindle, LS models: 3/4" spindle)
14 - rear stop assembly
15 - decal kit (6 pc.)
16 - high pressure hose
17 - hydraulic oil filler tube
18 - valve handle assembly
19 - breather cap
hydraulic valve assembly- **20**
hydraulic steel line (1 short & 1 long) - **21**
rubberride axle assembly - **22**
filter head - **23**
oil filter canister- **24**
hydraulic pump - **25**
hydraulic oil reservoir - **26**
hydraulic return hose - **27**
hydraulic suction hose - **28**
pump adapter - **29**
Honda Engine (see Honda manual) - **30**
high speed tire - turf tires on LS models (2) - **31**
If reordering high speed tires, indicate 4 or 5 bolt.
bumper - **32**
high speed hub assembly (2) - **33**
light box (2; left and right) - **34**
tail light (2; left and right) - **35**
reservoir sight glass (not shown) - **36**
coupler assembly between pump & engine (3 pc.) - **37**

Ph: 519.468.3647 Toll Free: 1.877.548.3473 Fax: 1.877.256.9131